

Fujia BMS-APP User Manual

Version: V00

Production/Date: Lan Zhongsheng / 2026.05.20

Review/Date:

Approval/Date:

Catalogue

Fujia BMS-APP User Manual.	1
1. Fujia BMS-APP Download Instructions (Images in this document are for reference only).	3
1.1 Download the Apple App.	3
2.1 Download the Android App.	3
II. Login Methods.	4
III. Bluetooth Mode.	5
bluetooth connection.	5
IV. Dashboard Interface.	6
V. Cell Data.	7
VI. Parameter Settings.	7
VII. Regarding.	8

I. Instructions for Downloading the Fujia BMS App (Images in This Document Are for Reference Only)

1.1 Download the Apple App

Method 1: Open the App Store → Search for "Fujia BMS" → Click Download



Method 2: Scan the QR code below with WeChat → click to download → navigate to the App Store → click to download



2.1 Download the Android App

Method 1: Scan the QR code above with WeChat → Click the [· · ·] icon in the upper right corner → Select to open with mobile browser → Click to download → Click to install →

II. Login Methods

Method 1: Log in using an existing account



Method 2: Click Create Account → Enter your phone number → Enter the verification code → Set a password → Click Register



III. Bluetooth Mode

Bluetooth Connection

Open the [Fujia BMS] App and connect using the following methods: Method 1: Connect already-added devices on the home screen

1. Select the device to connect



2. Auto-connect Device Redirection



Method 2: Search for and connect devices via Bluetooth

1. Click to Add Device




2. Click Bluetooth Search



2. Click the device to connect

4. Automatically add devices and redirect connections




Method 3: Scan the QR code to connect the device

1. Click the camera to scan the QR code
2. Scan the battery's QR code on the right to connect



3. Waiting for the device to recognize automatically

4. Automatically add devices and redirect connections




IV. Dashboard Interface

Instrument panel data interface: displays SOC, total voltage, total current, average voltage, maximum voltage, minimum voltage, voltage difference, charge/discharge time, charge/discharge status, charge/discharge MOS switch, balancing status, and protection status.




V. Cell Data

Cell Data Interface: Displays total voltage, number of cell strings, voltage per string, maximum voltage per string (in red), and minimum voltage per string (in blue).



VI. Parameter Settings

Function 1: Supports OTA Bluetooth online upgrades.



VII. Regarding

Function 1: Bind personal account information.

Function 2: Set up automatic Bluetooth connection.

Function 3: Switch Language (Currently supports only Chinese and English).

